



# WATERPROOFING INSTRUCTIONS

6010 N. Powerline Road, Ft. Lauderdale, FL 33309  
954-772-0300 • acrylux.com

## WATERPROOFING A BARREL TILE ROOF

1. Pressure clean the roof thoroughly.
2. Apply the primer of AC64 and water.
3. Fill all seams and any cracks with FIB Caulk.
4. Apply one (2) coat of Elasto - Premium.

- **Primer:** Mix 1 gallon of AC64 with 3 gallons of water and apply to the entire surface. Allow it to dry for approximately 1-2 hours.
- **FIB:** Brush FIB over all spaces between all tiles and any cracks or peeling.
- **Mastic:** Roll 2 coats of Elasto Premium to the entire surface (liberally).

## Coverage:

AC64 - approximately 1000 square feet per gallon.

FIB - dependant upon number and size of cracks.

Elasto-Premium - approximately 125 square feet per gallon.