



WATERPROOFING INSTRUCTIONS

6010 N. Powerline Road, Ft. Lauderdale, FL 33309
954-772-0300 • acrylux.com

WATERPROOFING A FLAT ROOF

(Waterproofing should only be applied to flat decks with positive drainage)

1. Lightly pressure clean entire roof if necessary.
 2. Apply the primer of AC64 and water.
 3. Apply two (2) coats of Mastic.
 4. Apply the finish coat of Roof Flat or Roof Gloss Paint.
- **Primer:** Mix 1 gallon of AC64 with 3 gallons of water and apply to the entire surface. Allow it to dry for approximately 1-2 hours.
 - **Mastic:** Roll 2 coats of Mastic to the entire surface and allow it to dry 24 hours between coats.
 - **Paint:** After 24 hours apply the finish coat of paint – Roof Flat or Roof Gloss.

Coverage:

AC64 - approximately 1000 square feet per gallon.

Mastic - approximately 125 square feet per gallon.

Paint - approximately 200 square feet per gallon.

Note: **Low lying areas can be leveled using a mixture of MC76 and sandmix.*

**Never tie in a flat roof to an existing pitched roof.*