



# WATERPROOFING INSTRUCTIONS

6010 N. Powerline Road, Ft. Lauderdale, FL 33309  
954-772-0300 • acrylux.com

## RECOATING A WATERPROOFED ROOF

1. Pressure clean the roof thoroughly.
2. Apply the primer of AC64 and water.
3. Repair any cracks with FIB Caulk.
4. Apply one (1) coat of Mastic.
5. Apply the finish coat of Roof Flat or Roof Gloss Paint.

- **Primer:** Mix 1 gallon of AC64 with 3 gallons of water and apply to the entire surface. Allow it to dry for approximately 1-2 hours.
- **FIB:** Brush FIB over any cracks or peeling (liberally).
- **Mastic:** Roll 1 coat of Mastic to the entire surface (liberally).
- **Paint:** After 24 hours apply the finish coat of paint – Roof Flat or Roof Gloss.

## Coverage:

- AC64** - approximately 1000 square feet per gallon.
- FIB** - dependant upon number and size of cracks.
- Mastic** - approximately 125 square feet per gallon.
- Paint** - approximately 200 square feet per gallon.