



6010 N. Powerline Road, Ft. Lauderdale, FL 33309
954-772-0300 • acrylux.com

WATERPROOFING INSTRUCTIONS

WATERPROOFING EXTERIOR WALLS

1. Pressure clean the walls thoroughly.
2. Fill all large cracks with Masonry Patch.
3. Apply the primer of AC64 and water.
4. Apply one (1) coat of Mastic.
5. Apply finish coat of Exterior Premium.

- **Masonry Patch:** Apply with a brush or putty knife to all cracks greater than hairline width.
- **Primer:** Mix 1 gallon of AC64 with 3 gallons of water and apply to the entire surface. Allow it to dry for approximately 1-2 hours.
- **Mastic:** Roll 1 coat of Mastic to the entire surface and allow it to dry 24 hours between coats.
- **Paint:** After 24 hours apply the finish coat of paint – Exterior Premium.

Coverage:

Masonry Patch - dependent upon condition of surface.

AC64 - approximately 1000 square feet per gallon.

Mastic - approximately 200 square feet per gallon.

Paint - approximately 250 square feet per gallon.