



WATERPROOFING INSTRUCTIONS

6010 N. Powerline Road, Ft. Lauderdale, FL 33309
954-772-0300 • acrylux.com

WATERPROOFING A SHINGLE ROOF

1. Pressure clean the roof thoroughly.
2. Apply the primer of AC64 and water.
3. Apply two coats of Fibered Roof Mastic, (cross-hatch coats).
4. Apply the finish coat of Roof Flat or Roof Gloss Paint.

- **Primer:** Mix 1 gallon of AC64 with 3 gallons of water and apply to the entire surface. Allow it to dry for approximately 1-2 hours.
- **FIB:** Brush FIB over any large gaps or spaces between tabs.
- **Mastic:** Roll 2 coats of Fibered Mastic to the entire surface (liberally).
- **Paint:** After 24 hours apply the finish coat of paint – Roof Flat or Roof Gloss.

Coverage:

- AC64** - approximately 1000 square feet per gallon.
- FIB** - dependant upon number and size of spaces.
- Mastic** - approximately 60 - 100 square feet per gallon.
- Paint** - approximately 200 square feet per gallon.